


Troubleshooting

TOILETS
CASSETTE TOILETS
C260

No flush C263



Check the well functioning of the pump



* Key words :


- 1 level : 1 level indicator
- ML : Multi-level
- POV : Powered outside vent
- EB : Electric blade
- WT : Waste transfer

Troubleshooting

No flush C262CWE



Check the well functioning of the pump




Troubleshooting

No flush C262SWE (toilet with separate flush tank)




Check the well functioning of the pump



Troubleshooting


No level indication Holding tank C260



Troubleshooting

Leakages

➤ Leak between the bowl and the holding tank



➤ Leakage on the holding tank

▪ Leak at the vent button

Replace the vent button
(part 0752492)

▪ Leak at the pour out spout

Replace the pour out
spout
(part 5071992)

▪ Leak at the blade of the holding tank

Replace the lipseal
(part 23721)